

INSTALLATION INSTRUCTIONS for Replacement Range Block covering Part Numbers 12001676CM, 330031CM, 5303935058CM, and WB17X5113CM

This Kit Contains:

- Range Block
- Horizontal & Vertical Mounting Clip
- 2x Wire Leads with Wire Connectors
- Instruction Sheet



Disconnect power before servicing.
Failure to do so can result in death or electrical shock.

Instructions

NOTE: When using Wire Nuts, follow correct wire nut best practices for installation. See Figure 1

1. Remove top burner, drip pan, and receptacle block mounting screw.
2. Remove the old receptacle block by cutting its 2 wire leads no more than 4-1/2" from the block.

CORRECT:

Let wire nut twist wires for a tight connection.



INCORRECT:

Wires twisted together prior to installing wire nut will not allow wires to form a tight connection.



FIGURE 1



3. Slide heat shrink tubing over both wires of new receptacle block.
4. Remove 3/8" to 1/2" of insulation from both range wires and attach to the wires of the new receptacle block using high temp wire nuts.
5. Slide the heat shrink tubing over the connection and heat indirectly with a match or lighter. See Figure 2

NOTE: Do NOT let the flame from the heat source touch the heat shrink tubing.

